

Surveliidmike paigaldamine

Nõuetekohase ühenduse kvaliteedi tagamiseks tuleb liitmikud paigaldada järgmiselt:

Ø 20 mm – Ø 40 mm

Lõigake toru täisnurga all, tehke vastava seadmega faas, määrige toru ots ja O-rõngas seebi või sarnaste omadustega vahendiga.



Keerake mutter lahti ja lükake toru O-rõngast mööda piirikusse.



Pingutage mutrit käsitsi, kuni tunnete takistust.



Ø 50 mm – Ø 110 mm

Asetage mutter, kinnitushülss ja O-rõngas paigaldamiseks ettevalmistatud torule.



Sisestage toru kruviliitmikusse kuni piirikuni, seejärel lükake O-rõngas ja survehülss sissepoole ja keerake mutter peale.



Pingutage mutrit mutrivõtmega, kuni tunnete takistust.



Tähelepanu! Paigaldamise ajal tuleb toru ja liitmik puhtana hoida.

Compression fittings assembly method

Ø 20 - 40mm



- Cut the pipe at right angles using pipe cutter. Chamfer the end of the pipe using chamfering tool. Lubricate the end of the pipe and the O-ring with soap or something similar.



- Slacken the ring nut and insert the pipe outside the o-ring until it stops.



- Tighten the ring nut until you feel a clear resistance.

Ø 50 - 110mm



- After preparing pipe end, unscrew the fitting, then put the ring nut, grip ring and o-ring.



- Insert the pipe into the fitting up to the pipe stop. Then slide the o-ring and the collet and tighten the ring nut.



- Tighten the ring nut with a nipple wrench until you feel a clear resistance.

Note!

Keep the pipe and fitting clean during the assembly process.